


6HV Series




Ordering code(Solenoid valve)



①Model	6HV: 5 port 2(3) position solenoid valve							
2Code	05: 0500 Series	1: 100 Series						
	10: Single	solenoid 5/2 way	20: Double soler	noid 5/2 way				
③Valve type	30C: Double solenoid 5/3 w	vay closed center	noid 5/3 way exhaust center					
	30P: Double solenoid 5/3 way pressure center							
4 Port size	M5: M5	M5	: M5	06:1/8"				
5Voltage	A: AC220V	B: DC24V	C: AC110V	F: DC12V				
6 Line length		050: 0.5m	200: 2.0m					
7Thread type	_		_	T: NPT				

Ordering code(DIN guide rail)



1 Model	6HV: 5 port 2(3) position solenoid valve									
2Code	0500M: DIN guide rail for 0500 Series	100M: DIN guide rail for 100 Series								
	4F: Manifold for 2、3、4 stations	4F:Manifold for 2、3、4 stations	20F:Manifold for 19、20 stations							
	7F: Manifold for 5 6 7 stations	6F:Manifold for 5 6 stations	22F:Manifold for 21 22 stations							
	10F: Manifold for 8 \ 9 \ 10 stations	8F:Manifold for 7、8 stations	24F:Manifold for 23、24 stations							
③Number	12F: Manifold for 11、12 stations	10F:Manifold for 9、10 stations								
of stations	15F: Manifold for 13、14、15 stations	12F:Manifold for 11、12 stations								
	18F: Manifold for 16、17、18 stations	14F:Manifold for 13、14 stations								
	21F: Manifold for 19、20、21 stations	16F:Manifold for 15、16 stations								
	24F: Manifold for 22、23、24 stations	18F:Manifold for 17、18 stations								

[Note] DIN guide rail contents inlet and outlet module or end cover. The detail configuration is: ten and less stations config one inlet and outlet module and one end cover, ten over stations config two inlet and outlet modules.

Product feature

- 1. Electrical entry is terminal, horizontal and vertical insertion can freely switch.
- 2. Inner exhaust structure, which can collect pilot airflow, and then exhaust intensively from R, S port.
- 3. Internal hole adopts special processing technology which has little attrition friction, low start pressure and long service life.
- 4. The solenoid valve and the DIN rail are connected by a push-pull type, which can be integrated into the valve group with multiple valves. It is convenient and flexible to disassemble and replace.





6HV Series

Specification

Model		6HV0510 6HV0		6HV0530	6HV110	6HV120	6HV130			
Port size [N	ote1]		In=Out=M5			In=Out=M5(or=	:1/8")			
Orifice size (Cv)[Note4]		M5:3.4mm²(0.2)		6HV0530CM5: 2.2mm ² (0.13)	06:8.9mm²(0.52)		6HV130C06: 8.0mm ² (0.47)			
Max. freque	ency [Note2]	5 cyc	le/sec	3 cycle/sec	5 cyc	cle/sec	3 cycle/sec			
Fluid		Air(to be filtered by 40µm filter element)								
Acting		Pilot								
Operating	6HV0530/6HV130	29~114psi(0.2~0.8MPa)								
pressure	Othres	21~114psi(0.15~0.8MPa)								
Proof press	ure	175psi(1.2MPa)								
Temperatur	re			-20~	-70℃					
Material of	body	Aluminum alloy								
Lubrication	[Note3]	Not required								
Exhaust typ	e of pilot valve	Main valve and pilot valve is centralized exhaust								


[Note1] NPT thread is available.

[Note2] Once lubricated air is used, continue with same medium to optimise valve life span. Lubricants like ISO VG32 or equivalent are recommended.


[Note3] The maximum actuation frequency is in the no-load state.

[Note4] Equivalent orifice S and Cv are all calculated from the flow rate data.

Inner structure



No.	Item	No.	Item	No.	Item
1	Pilot valve	6	Spool	11	Bolt
2	Manual override	7	Bracket	12	Steel ball
3	Pilot kit	8	Little piston	13	Spring
4	Big piston	9	Gasket	14	Return holder
5	Body	10	Bottom cover	15	Side cover







6HV Series

Coil specification

Item	Specification							
Standard voltage	AC220V	AC110V	DC24V	DC12V				
Scope of voltage	AC: +15	% ~ -10 %	DC: ±10%					
Power consumption	1.1	.VA	0.9W					
Protection		Dust	oroof					
Temperature classification		F CI	ass					
Electrical entry								
Activating time	0.05 sec and below							

Flow chart






The data in flow rate chart are obtained from AirTAC lab.

Dimensions






Item\Stations	2F	3F	4F	5F	6F	7F	8F	9F	10F
L	105	105	105	140	140	140	175	175	175
LA	70	70	70	105	105	105	140	140	140
LB	53	64	74.5	85	95.5	106	116	127.5	138
LC	26	20.5	15	27.5	22	17	29.5	23.8	18.5




6HV Series

6HV0500+6HV0500M11F~24F



6HV0500M11F~24F Guide rail




Item\Stations	11F	12F	13F	14F	15F	16F	17F	18F	19F	20F	21F	22F	23F	24F
L	210	210	245	245	245	280	280	280	315	315	315	350	350	350
LA	175	175	210	210	210	245	245	245	280	280	280	315	315	315
LB	164.5	175	185.5	196.5	207	217.5	228	238.5	249.5	260	270.5	281	292	302.5
LC	23	17.5	30	24	19	31	26	21	33	27.5	22	34.5	29	24




6HV Series

6HV100+6HV100M2F~10F



6HV100M2F~10F Guide rail






Item\Stations	2F	3F	4F	5F	6F	7F	8F	9F	10F
L	140	140	140	175	175	210	210	245	245
LA	105	105	105	140	140	175	175	210	210
LB	70	85.5	101	116.5	132	147.5	163	178.5	194
LC	35	27	19.5	29	21.5	31	23.5	33	25.5




6HV Series

6HV100+6HV100M11F~24F



6HV100M11F~24F Guide rail




Item\Stations	11F	12F	13F	14F	15F	16F	17F	18F	19F	20F	21F	22F	23F	24F
L	280	280	315	315	350	350	385	385	420	420	455	455	490	490
LA	245	245	280	280	315	315	350	350	385	385	420	420	455	455
LB	228.5	244	259.5	275	290.5	306	321.5	337	352.5	368	383.5	399	414.5	430
LC	28	18	28	20	30	22	32	24	34	26	36	28	38	30



6HV Series

Installation and Application(Integrated Solenoid valve)



Configations of integrated solenoid valve:

NO.	Name of module	How to order	Note		
1	Inlet and outlet module	Contains in the DIN guide rail, can't be ordered independently	Left and right positions are interchangeable		
2	DIN Guide rail	Refer to ordering code for detail			
3	Solenoid valve (Single solenoid(5/2 Way))	Refer to ordering code for detail			
4	Solenoid valve (Double solenoid(5/2 Way))	Refer to ordering code for detail	It can be installed at any position and can be added or removed at wil		
(5)	Solenoid valve(5/3 Way)	Refer to ordering code for detail			
6	End cover	Contains in the DIN guide rail, can't be ordered independently	Left and right positions are interchangeable		

- 1. The integrated solenoid valve group is a highly integrated valve block consisting of a solenoid valve, an inlet and outlet module, a end cover, and a DIN guide rail.
- 2. Each functional module in the integrated solenoid valve group can be freely replaced, the number of stations can be increased or decreased according to demand.
- 3. The method of increasing stations:
 - 1 Loosen the stop screw. a

2Separate the original solenoid valves that you wish to add.

 $\centsymbol{3}$ The newly added solenoid valve is mounted on the DIN rail according to the "Fig. 1" method.


4 Push the other functional modules to make them tightly connected, then tighten the stop screws (a) to complete the increasing stations.

- 4. Notice:
- 4.1) Stop screw tightening torque: 6HV0500: 1N.m/6HV100: 1.4N.m.
- 4.2) Fastening method: first fix one end cover, then push each function module hard so that there is no gap between the valves, then tighten the stop screw at the other end.
- 4.3) When reassembling: If the connection between the valves and the tightening torque of the stop screw are insufficient, air leakage may occur. Before ventilating, please make sure there is no gap between the valves, and firmly fix it on the guide rail before venting.
- 5. The method of removing the solenoid valve from the DIN rail: Refer to the requirements of "Fig. 2" for details.





6HV Series



6